



TECHNICAL DATASHEET

Product code : **E2278 +2378**

JACKET + TROUSERS D3E3 SPECIAL ALUMINUM SPLASHES

Description :

made of fire retardant satin fabric 360g / m² navy blue.

43% Cotton / 30% Viscosis / 20% Acrylic Type F / 6% Para-aramid / 1% Antistatic.

Jacket: snap fastening under collar-collar - wrist tightening - patch pockets with flap + velcro (2 basses + 1 chest + 1 inner wallet)

Trousers: belt loops-button button at the waist and snaps at the fly- 2 italian pockets + 1 back pocket with flap



Dimensions :

Sizes available S to 3XL

flame protection and small splashes of molten metal -in case of heavy spraying or intense radiant heat wear an aluminized PPE marked C3 D3 E3 - recommended for molten aluminum


Recommendation

The materials of this article do not contain any substance that can harm the health of the user

This PPE is in conformity with the requirements of the Directive 89/686/CEE.

Article undergoing certification at CENTEXBEL (Laboratory n°0493) , UE file Number 12317

The CE marking on these items means the respect for the essentials requirements of European Directive on PPE based on the standard Iso 13688



A1A2B1C1D3E3F1

SO 11612 (Fabric Performance)

A1 CLASSE 1

ISO 11611

A Limited flame spread

B Convective Heat

C Radiant Heat

D Projection of molten aluminium

E Projection of molten iron

F Contact Heat

(1 à 3)

(1 à 4)

(1 à 3)

(1 à 3)

(1 à 3)

Use only within the risks covered above


Maintenance :



A dirty clothe may cause a reduced protection/ maximum temperature of 75 ° C - wash like cotton - no bleach

Storage : Protected from the light and in a dry place, free of moisture, oils, greases...

Recommandation : jacket and trousers must be worn together - PERMANENT fireproof treatment - must be worn with appropriate PPE



Coat/Apron

Lenght	A	Sizes	B et C
120 cm	164-170 cm	S – T2	92-96 cm
130 cm	170-182 cm	M – T3	96-104 cm
140 cm	182-188 cm	L – T4	104-112 cm
150 cm	188-194 cm	XL – T5	112-120 cm
160 cm	194-200 cm	XXL – T6	120-128 cm

For coveralls, take the greatest size between **B** or **C**. The measures must be taken on the person wearing his work clothes, because this equipment is worn over. In doubt between two sizes choose the larger one.